

MXL2 Dash Logger

USER GUIDE



AiM Srl.
Via Cavalcanti, 8
20063 Cernusco S/N (MI)
Italia
Tel. (+39) 02.9290571

www.aim-sportline.com

Made in Italy



MXL2 Dash Logger

- 04 1. INTRODUCTION
- 06 2. WHAT IS IN THE KIT
- 08 3. LAYOUT AND PUSHBUTTONS
- 10 4. GEAR FLASHES AND ALARM LEDS
- 11 5. ECU CONNECTION
- 12 6. RPM
- 12 6.1 RPM FROM ECU
- 12 6.2 RPM VIA A 5-50 V SQUARE WAVE SIGNAL OR COIL (150-400 V)
- 14 7. SPEED
- 14 7.1 SPEED READ FROM ECU
- 14 7.2 SPEED READ FROM GPS RECEIVER
- 14 7.3 SPEED READ FROM WHEEL SENSOR
- 16 8. ANALOG INPUTS
- 17 9. DIGITAL OUTPUTS
- 18 10. RACE STUDIO 3 SOFTWARE
- 19 10.1 CONFIGURATION
- 21 10.1.1 DISPLAY CONFIGURATION
- 22 10.1.2 CHANNELS CONFIGURATION
- 23 10.1.3 ECU STREAM CONFIGURATION
- 23 10.1.4 ALARM LEDS, DIGITAL OUTPUT AND SHIFT LIGHTS
- 26 10.1.5 MODIFY OR DELETE AN EXISTING CONFIGURATION
- 27 10.2 CONNECT YOUR MXL2 TO A PC
- 27 10.2.1 CONFIGURING TRANSMISSION
- 28 10.2.2 ONLINE VIEW AND CALIBRATION
- 29 10.2.3 DATA DOWNLOAD
- 30 11. GPS AND TRACK MANAGEMENT
- 30 11.1 TRACK FEATURE
- 32 11.2 FILTERS IN TRACK DATABASE MANAGEMENT
- 34 11.3 HOW TO ADD A NEW TRACK TO THE PC DATABASE
- 36 11.4 HOW TO MODIFY TRACK DATA IN THE PC DATABASE
- 37 11.5 HOW TO READ, WRITE AND DELETE TRACK INFORMATION
- 39 EXPANSION
- 40 MXL2 PINOUT
- 42 TECHNICAL DRAWINGS



Thanks.

Dear Customer,

First, we would like to thank you for choosing the MXL2 dash logger as the tool for improving your racing craft setup and on-track performance.

The MXL2, with its high contrast display, advanced expansions and sampling capabilities, gives you the flexibility for reviewing your data in your preferred way and recording them from a variety of sensors and sources.

Please, before digging into your new data system, keep in mind that we are constantly working on bettering our software and firmware.

So, be sure to check our website periodically for any updates.

www.aim-sportline.com



What is MXL2?

MXL2 is a color, high-contrast brilliant traditional LCD dash logger developed for race car installations. It is fully customer configurable.

Which data does it manage?

Data come from a wide range of sources, including your vehicle ECU, the internal accelerometers and gyro, the GPS module included in the kit, the analog/digital inputs, the external expansions as well as predefined math channels.

How many pages does it show?

You can define up to eight different fully customizable pages.

Is it possible to configure the pages?

You can choose among a wide library of page styles, defining the data to be shown. End of scales and units of measure can be easily configured, using the RaceStudio3 software included in the kit.

How do alarm LEDs work?

You can configure alarm LEDs choosing color, blinking frequency and defining the logic for turning them on or off.

What is it possible with WiFi?

You can use a WiFi connection for transmitting the data of your test, sending data online and for configuring the system.

Are the data recorded by MXL2 compatible with the old MXL and EVO4 data?

Yes, MXL used to produce data in DRK format. MXL2 offers an improved data management and produces XRK format that only RaceStudio3 can read.

Nevertheless, the last releases of RaceStudio2 can detect XRK files and transform them into old DRK format files that are compatible with MXL1 and EVO4 files.

What is the difference between the old DRK format and new XRK?

XRK, taking advantage of GPS technology, associates absolute time and GPS position to each data with the precision of 1 millisecond. In this way, it is possible to better compare different laps and tests.

What about RaceStudio3? What are the differences between the old DRK format and new XRK?

RaceStudio3 is the new software for managing configuration, data download and data analysis for all the future AiM systems. It is going to substitute RaceStudio2, which has accompanied us for almost 15 years. Based on a totally new and much more flexible architecture, it is a work in progress; some features still have to be developed, so they are actually shared with RaceStudio2.

We are going to upgrade it very often, so, please, don't forget to check our web site at www.aim-sportline.com.



2. What is in the kit

The MXL2 kit includes:

MXL2 dash logger



Harness




GPS05 module



Software



MXL2 Dash Logger




4. Gear Flashes and Alarm LEDs

1

MXL2 features 10 RGB gear flash LEDs that can be freely configured in a very flexible way. For each LED, you can define the RPM

value at which to turn it on and the colour. You can also define different RPM values of each gear number.



2

MXL2 also has 6 different alarm LEDs that you can configure in order to turn them on or off depending on the value of the analog or digital inputs, ECU values, expansion values, GPS information or math channels.

You can configure them in order to turn them off when the condition disappears, when you push a pushbutton, when the test is finished or when the data are downloaded after the test.

You can associate an alarm LED, a message and a digital output with each event.

Please, read section 10.1.4 in order to see how to manage gear flashes and alarm LEDs.

5. ECU connection

MXL2 can acquire data from the ECU of your vehicle. The list of the ECU protocols available is published on our site: [www.aim-sportline.com/download area, ecus connections](http://www.aim-sportline.com/download_area/ecus_connections).

This list includes approximately 500 different protocols and is constantly updated with new protocols and upgrades published every week.

When possible, documents explaining how to configure your ECU to ensure compatibility between the data flow transmitted are available, too.

From an hardware point of view, MXL2 is compatible with all currently available connections: CAN, RS232 or K line.

The steps to manage the data coming from the ECU are the following:

1. Determine which hardware connection is available for your ECU.
2. Read the documentation about your ECU at www.aim-sportline.com and identify the name of the proper software driver to be specified.
3. Using Race Studio 3, configure MXL2 setting your ECU driver with the menu shown here below, that appears when you create a new configuration.



The ECU has to be set when configuring your MXL2 with RS3 configuration software. The steps are explained in section 10.1.

6. RPM

MXL2 can receive the RPM signal from three different sources:


- From ECU
- Through a square wave signal (8 to 50 V)
- From the low voltage (from 150 to 400 V) of the coil

6.1 RPM from ECU

To get RPM from the ECU please configure your MXL2 and enable RPM channel as explained in section 10.1. RPM is one of the many data flowing from your ECU to MXL2.



6.2 RPM via a 5-50 V Square Wave Signal or coil (150-400 V)

In case your engine is not managed by any ECU, MXL2 can read the signal from the low voltage of the coil (whose peak can be from 150 to 400 V) or from a possible square wave (the peak can be from 5 to 50V). The pin labelled "RPM" reported in appendix "Pinout" receives the signal:



The image shows an example of wiring for the ignition system.

The output, labelled "GREY TACH" gives a 5-50V output that can be directly acquired from MXL2. If the output is not available from the ignition system, the system has to be connected to the low voltage of the coil, as shown in the following schematic.



- Point 1:** Low voltage of the coil
- Point 2:** Connected to the spark plug
- Point 3:** Connected to the +12V of the battery

After connecting the RPM signal, please use the software RaceStudio3 for enabling the RPM channel, as explained in section 10.1.2

7. Speed

MXL2 can receive the speed signal from three different sources:

- From the ECU
- From the GPS receiver included in the kit
- From the wheel sensors (digital channels)

It is therefore possible for MXL2 to receive and store different values of speed at the same time; the more powerful ECUs transmit up to four wheel speed values.

7.1 Speed read from the ECU

If your ECU sends the value of speed in its data stream, it is obviously possible to read, record and show that value.

Simply enable its using in the software RaceStudio3, as explained in section 10.1.

7.2 Speed read from the GPS receiver

The GPS receiver integrated in the MXL2 kit is configured in order to obtain the best performance in terms of reactivity and accuracy.

For getting GPS speed, you don't need any configuration. Simply connect the GPS05 Module to your MXL2 and after a setup period of some seconds, the data will be received and automatically recorded.

7.3 Speed read from wheel sensors

MXL2 has four wheel speed inputs, one in the 37 pins connector and the other three in the 22 pins connector:

The digital sensor X05SNBS00 detects the presence of a metallic tooth placed at a distance between 0.5 and 2 mm.



Please use the software RaceStudio3 for configuring the system.

Just enter the program configuration panel and, after enabling the desired speed channels, set the wheel circumference and the number of pulses per revolution.

Id	<input checked="" type="checkbox"/>	Name	Function
RPM	<input checked="" type="checkbox"/>	RPM	<i>RPM</i>
Spd001	<input checked="" type="checkbox"/>	Speed001	<i>Vehicle Spd</i>
Spd002	<input checked="" type="checkbox"/>	Speed002	<i>Vehicle Spd</i>
Spd003	<input checked="" type="checkbox"/>	Speed003	<i>Vehicle Spd</i>
Spd004	<input checked="" type="checkbox"/>	Speed004	<i>Vehicle Spd</i>

8. Analog Inputs

MXL2 has 8 analog inputs, recorded up to 1000 times per second each. You can connect:

- 0-5 Volt signals
- Ratiometric potentiometers
- Pressure sensors
- Thermo-resistances
- K-type thermocouples

Please use the following steps, using the software RaceStudio3 as explained in section 10.1:

- Connect the sensor to the desired input
- Enable the channel in the Channels table
- Select the proper sensor type; sensors of many different types are properly handled
- Set the sampling frequency
- Set the unit of measure.

■ Temperature sensors

K thermocouples
Thermo-PT100 resistors
Temperature sensors VDO

■ Pressure sensors

VDO 40-120 ° C
VDO 50-150 ° C
VDO 60-200 ° C
MSI 0-2 bar
MSI 0-5 bar
MSI 0-10 bar
MSI 0-2000 psi

■ Potentiometers

Distance
Zero-based
Zero Central

■ Generic sensors

0-50 mV
0-500
0-5 V

9. Digital Output

MXL2 features two digital outputs in the 22 pins connector.

Each of them can give an output of 1 amp at 12 volts.

You can configure them in order to turn them on or off depending on the value of the analog or digital inputs, ECU values, expansion values, GPS information or math channels.

To each event you can associate an alarm LED, a message and a digital output.

You can configure them in order to turn them off when the condition disappears, when you push a pushbutton, when the test is finished or when the data are downloaded after the test.

Please refer to section 10.1.4 in order to see how to manage the digital outputs.

The screenshot shows the RaceStudio3 3.01.14 interface with the 'Channels' tab selected. The table below represents the data visible in the interface:

Id	Name	Function	Sensor	Unit	Freq	Parameters
RPM	<input checked="" type="checkbox"/> RPM	RPM	RPM Sensor	rpm	20 Hz	max: 10000; factor: 1;
Spd1	<input checked="" type="checkbox"/> Speed1	Vehicle Spd	Speed Sensor	kmh 0.1	20 Hz	wheel: 1666; pulses: 1;
Spd2	<input checked="" type="checkbox"/> Speed2	Vehicle Spd	Speed Sensor	kmh 0.1	20 Hz	wheel: 1666; pulses: 1;
Spd3	<input checked="" type="checkbox"/> Speed3	Vehicle Spd	Speed Sensor	kmh 0.1	20 Hz	wheel: 1666; pulses: 1;
Spd4	<input checked="" type="checkbox"/> Speed4	Vehicle Spd	Speed Sensor	kmh 0.1	20 Hz	wheel: 1666; pulses: 1;
Ch01	<input checked="" type="checkbox"/> Channel01	Voltage	Generic 0-5 V	mV	20 Hz	
Ch02	<input checked="" type="checkbox"/> Channel02	Voltage	Generic 0-5 V	mV	20 Hz	
Ch03	<input checked="" type="checkbox"/> Channel03	Voltage	Generic 0-5 V	mV	20 Hz	
Ch04	<input checked="" type="checkbox"/> Channel04	Voltage	Generic 0-5 V	mV	20 Hz	
Ch05	<input checked="" type="checkbox"/> Channel05	Voltage	Generic 0-5 V	mV	20 Hz	
Ch06	<input checked="" type="checkbox"/> Channel06	Voltage	Generic 0-5 V	mV	20 Hz	
Ch07	<input checked="" type="checkbox"/> Channel07	Voltage	Generic 0-5 V	mV	20 Hz	
Ch08	<input checked="" type="checkbox"/> Channel08	Voltage	Generic 0-5 V	mV	20 Hz	
AccX	<input checked="" type="checkbox"/> AccelerometerX	Inline Accel	AM Internal Accelerometer	g 0.01	20 Hz	
AccY	<input checked="" type="checkbox"/> AccelerometerY	Lateral Accel	AM Internal Accelerometer	g 0.01	20 Hz	
AccZ	<input checked="" type="checkbox"/> AccelerometerZ	Vertical Accel	AM Internal Accelerometer	g 0.01	20 Hz	

10. RaceStudio3 Software

RaceStudio3 is the powerful software that you are going to use for all the activities regarding your MXL2. It offers the following features:

MXL2 configuration:

Create, modify, delete, export and import configurations with all Channels, ECU drivers, Math channels, Display pages, Alarm, Digital outputs, Shift lights and all the expansions.

When you start RaceStudio3 with your MXL2 connected and switched on, you can see a pushbutton in the upper left position of the screen; this lets you swap between different features:

- Configurations
- Tracks
- Analysis
- Movies
- Preferences
- Web Updates



Configurations

Creates, imports, exports and modifies existing configurations.

Tracks

Creates, imports, exports and modifies the map of your racing tracks.

Data analysis

For looking at and comparing your data.

Movies

For watching and comparing up to two track laps.

Preferences


For setting software language and measure units (pressures, speed, temperature, brake and oil pressure).

Web updates

Downloads new firmware and software releases from our site www.aim-sportline.com to automatically upgrade your MXL2.

RaceStudio3 software is provided on a CD included in the MXL2 kit or can be downloaded from Download area of www.AiM-Sportline.com

10.1 Configuration





The configuration page is divided into two sections.

The left side is dedicated to the folders that you can create and manage in order to better organize your configurations. Simply push the **[+]** pushbutton in order to create a new one.

When you connect an AiM logger, like your MXG, its serial number appears in the left side of your screen. In the right side of the screen you can see all the configurations of the selected folder. Please click on the desired one for editing it or push the **"NEW"** pushbutton for creating a new one.

Please don't forget to select the proper ECU Manufacturer and model to which connect your MXL2.




After having entered the MXL2 configuration page you can see different tabs, which are useful for selecting one of the following configuration features:

- Channels
- Ecu stream
- Shiftlights and Actions
- Display



10.1.1 Display Configuration

After selecting the **DISPLAY** configuration feature, the following page appears:



It is divided into two different sections.

On the right, you can select one of several different layouts, while on the left you will manage the different fields, selecting the proper information to be shown, the parameters, labels and the units of measure.

You can add up to eight pages.

Please use the lower left part of the display for configuring each channel.

You can define:

- The channel,
- The label,
- The unit of measurement
- The end of scale for each channel shown on the page (scale)

When the panel shows the desired configuration, push **"SAVE"** or **"CLOSE"** for saving the configuration.

In case you have connected your MXL2 to the PC, the **"TRANSMIT"** pushbutton is available for transmitting the new configuration to your device.

10.1.2 Channels Configuration

Push the tab CHANNELS:



The channel configuration page will appear


With this page you can define all the parameters for your analog inputs, speed inputs and digital RPM input.

Id	<input checked="" type="checkbox"/>	Name	Function	Freq	Parameters
RPM	<input checked="" type="checkbox"/>	RPM	RPM	20 Hz	
Spd001	<input checked="" type="checkbox"/>	Speed001	Vehicle Spd	20 Hz	
Spd002	<input checked="" type="checkbox"/>	Speed002	Vehicle Spd	20 Hz	
Spd003	<input checked="" type="checkbox"/>	Speed003	Vehicle Spd	20 Hz	
Spd004	<input checked="" type="checkbox"/>	Speed004	Vehicle Spd	20 Hz	
Ch001	<input checked="" type="checkbox"/>	Channel001	Pct	20 Hz	
Ch002	<input checked="" type="checkbox"/>	Channel002	Pct	20 Hz	
Ch003	<input checked="" type="checkbox"/>	Channel003	Pct	20 Hz	

By clicking on each line, a menu appears:

You can define:


- The name of the channel
- The function
- The sensor connected
- The sampling frequency
- The measure unit
- The measure precision
- The measure filter level



10.1.3 ECU Stream Configuration


With this feature, you can enable or disable the data coming from your ECU, and you can define.


- The name
- The sampling frequency
- The measure unit
- The measure precision



10.1.4 Alarm LEDs, Digital Output and Shift Lights

Click **“Shift Lights and Actions”** for managing the Shift Light LEDs, Alarm LEDs and Digital Outputs.





Shift Lights Configuration


Using the configuration bar you can manage, for each LED the color and RPM threshold value that will turn it on.

Pushing the pushbutton **“Option”** you can decide:

To keep the LED ON if its threshold is exceeded or to keep the LED ON only until another LED is turned ON.

And if the LEDs are managed according to the engaged gear number.

In this case, for each gear number you have to define the levels at which to turn them on.



Alarms Configuration

When you click **“Add new trigger”** the window shown in the above picture appears. There you can define the event the system has to check and the effect of that event.

1) Fill the DESCRIPTION field, in order to easily identify the event in the future.

2) Describe the Alarm: it can be a simple event, like, for example:

“Water temperature is higher than 100 C”
or a combination of multiple events, like, for example:

“Water temperature is higher than 100 C”
and “Engine RPM is higher than 6000”
You can add different check lines and define the alarm as a combination of ALL the events or just ONE of them.

3) Describe what to do when an alarm arises: MXL2 can:

4) Turn a LED ON: You have to select the color and the behaviour (fast/slow blinking or continuous).

5) Show a TEXT MESSAGE that you have to create and define.

6) Finally, you have to configure till when the alarm has to remain in evidence.

There are some options:

- Until when the condition is no longer met
- Until when the device is turned OFF
- Until when a button is pushed
- Until when data is downloaded

Once the configuration is set, a summary will appear: any time you need to change settings, just click on the icon and proceed.

The icon at the left recalls the condition you chose to turn the LED off.



10.1.5 Modify or Delete an Existing Configuration

For modifying an existing configuration, select the desired configuration to be modified and double click on it.

To delete an existing configuration, click on it and select delete.




Then, proceed like in the creation of the configuration.

10.2 Connect Your MXL2 to a PC

When you connect your MXL2 to the PC, it is automatically recognized, and on the left side of the PC display the name of your device appears, as shown in the picture. At this point, you can execute the following functions:

- Transmit the configuration
- On Line view
- Calibration
- Data download


This is explained in the next paragraphs.



10.2.1 Configuration Transmission

When you connect an MXL2 to your PC, the **“TRANSMIT”** pushbutton appears at the top of the configuration page.

Simply push it and the configuration will be transmitted.



10.2.2 On Line View and Calibration

Auto calibrate		Start recording	
Lap Time	0:00.000	GPS	No GPS
Logger Temperature	28.6 C	Battery Voltage	12680 mV
RPM	0 rpm	Speed1	0.0 km/h
Speed2	0.0 km/h	Speed3	0.0 km/h
Speed4	0.0 km/h	Channel01	0 mV
Channel02	121 mV	Channel03	123 mV
Channel04	123 mV	Channel05	123 mV
Channel06	120 mV	Channel07	125 mV
Channel08	127 mV	AccelerometerX	-0.05 g
AccelerometerY	0.00 g	AccelerometerZ	1.01 g
GyroX	-1 deg/s	GyroY	-1 deg/s
GyroZ	3 deg/s		

Push **"LIVE MEASURE"** for looking at the data coming from your MXL2. You can change the measure of unit by double-clicking on the measure.

From the Online View, you can calibrate the channels that require calibration.

10.2.3. DataDownload

Name	Date	Size
m_0043.xrk	11:45	24 KB
m_0042.xrk	11:45	23 KB
m_0041.xrk	11:42	18 KB
m_0040.xrk	11:42	44 KB
m_0039.xrk	08:41	15 KB
m_0038.xrk	08:41	17 KB
m_0037.xrk	08:06	16 KB
m_0036.xrk	May 27 08:36	6.343 KB
m_0035.xrk	May 26 15:17	819 KB
m_0032.xrk	May 26 14:09	585 KB
m_0031.xrk	May 26 10:52	97 KB
m_0030.xrk	May 26 10:44	2.750 KB
m_0029.xrk	May 26 08:53	17 KB
m_0028.xrk	May 26 08:53	38 KB
m_0027.xrk	May 26 08:52	1.405 KB
m_0026.xrk	May 26 06:33	542 KB
m_0024.xrk	May 26 06:28	834 KB
m_0023.xrk	May 26 06:21	651 KB
m_0022.xrk	May 26 06:15	965 KB
m_0021.xrk	May 23 19:29	36 KB
m_0021.xrk	May 23 19:28	173 KB

Push **"DOWNLOAD"** for downloading the data recorded in your MXL2.

You will see the information about the files recorded in the system: dimension and date/time of the file creation.

Please select a file and push **"DOWNLOAD"** for transferring it to your PC.

11. GPS and Track Management

The GPS Module, included in the MXL2 kit, provides the following information, updated ten times per second:

- Position (latitude, longitude, altitude)
- Speed
- Longitudinal acceleration
- Lateral acceleration

If MXL2 knows the finish line of the track and the split coordinates, it can calculate and show:

- Lap Times
- Split times

To transmit track information to MXL2, use the Track Manager feature, as explained in the following section.

11.1 Tracks Feature

With Tracks you can update, modify, transmit and receive to and from MXL2 the coordinates of the finish line and split points of all the tracks you are going to run.


When opening the software, if there is no system connected to your PC via USB cable, you will see the screen shown here on the right.

As you can see, the screen is divided into two parts.

On the left you see the track list.

If available, you will see the track layout and the type of vehicle that usually races on the track: car, motorcycle or kart.

On the right side of the screen, you will find a big picture of the track.




- 1 Static filter button
- 2 Selection window for dynamic filters
- 3 Track type: car, bike, karts
- 4 Track setting
- 5 Track shape, with starting line and split points position
- 6 Small track shape
- 7 Track selection check box
- 8 View/hide country tracks



11.2 Filters in Track Data Base Management

You can filter the list of tracks you need in different ways.

The filters can be static (1) recorded and used every time you use Track Manager, or dynamic (2) not saved when quitting the program.



Static Filters

A static filter is activated by the button "filter" [1].

The window shown here on the right appears.



It allows you to select nations, type of vehicle and type of circuit.

The lists show only countries, vehicles and types of circuits present at least once in the database.

For example, if the database does not include any track in Germany, this country will not appear in the list.

By default, all countries, types of vehicles and tracks are enabled.

If you are interested in only the car tracks, for example, you must disable karts and motorcycles.

Dynamic Filters

The dynamic filters are activated by the top left box of the screen [2]:

The dynamic filters allow you to further filter the tracks by merging different characteristics.

For example, when writing "Spain kart," you will see only kart circuits in Spain.


11.3 How to Add a New Track to the PC Database

The official AiM track Database is continuously growing. To update your PC database, you can import the new tracks:

Press **“Options”** then **“Import Tracks from AiM Website”**.

To add a new track:

1) Press the button **“New.”**



2) Enter the name of the track.




3) Enter the required information:

Track name, Nation, type of circuit (**closed, oval or point to point**) and surface (**asphalt, dirt, ice, mixed or water**).


Finally, using the icon buttons, set the type of vehicle that usually runs on the circuit: **cars, motorcycles or karts**.

If you have already run a test on the track and have downloaded data, you can associate the shape of the track by pressing **“Load Shape”** button.



You can now select the **“.GPK”** file containing the GPS map of your track session.

Please select the proper file, carefully checking the name, date and time of the files.



Map of Your Track Session

The shape of the track appears, split in different laps of the test. Using the keyboard highlighted here on the right it is possible to scroll through the different laps, zoom and rotate the drawing (4).


After having selected the desired lap, push **“OK”** to save the image of that lap. That image will be used as a reference shape.

Finish line coordinates are automatically calculated but can be modified as desired in one of the following ways:

Filling in latitude and longitude (5).

Placing the cursor on the desired point of the track and clicking the **“Cursor Pos”** button. (6).


In case of a point-to-point track, it is necessary to define the coordinates of the starting and finish line. Push **“OK”** to save the configuration.



11.4 How to Modify Track Data in the PC Database

Click the setting icon show here on the right.


The window containing the track data will open.



11.5 How to Read, Write and Delete Tracks Information in MXL2

Connect your system to your PC using the USB cable.

The Track Manager screen will display two lists. On the left are the tracks in your PC and on the right are the tracks in MXL2.




To transmit track information to MXL2

Select tracks to be submitted by clicking on the square check box or on the name of the track.

Drag in the right panel or press button ▶

The tracks' information is updated in the SmartyCam panel.




12. Expansion

To receive track information from MXL2

Select tracks to be submitted by clicking on the square check box or on the name of the track.


Drag in the left panel or press button ◀

Tracks' information is updated in the PC list.




Using our built in CAN bus, add expansion modules like GPS, external memory modules, channel expansions, lambda controllers. These are only some of the items that can be added to our MXL2 range for incrementing the performance and the data acquired.

13. MXL2 Pinout



PIN	Deutsch 37pin.
01	9-15V power in
02	gnd batt
03	can+ Exp
04	gnd
05	+Vbatt can
06	can- Exp
07	+Vbext
08	Can1+ Ecu
09	Can1- Ecu
10	gnd
11	k line Ecu
12	USB D+
13	USB D-
14	gnd
15	rpm
16	gnd
17	+Vbatt
18	Optical lap
19	speed1
20	gnd
21	+Vbatt
22	Ain1
23	gnd analog
24	+Vbatt
25	+Vref
26	Ain2
27	gnd analog
28	+Vbatt
29	+Vref
30	Ain3
31	gnd analog
32	+Vbatt
33	+Vref
34	Ain4
35	gnd analog
36	+Vbatt
37	+Vref




PIN	Deutsch 22pin.
01	Ain5
02	gnd analog
03	+Vbatt
04	+Vref
05	Ain6
06	Ain7
07	gnd analog
08	+Vbatt
09	+Vref
10	Ain8
11	speed2
12	gnd
13	+Vbatt
14	speed 3
15	speed4
16	gnd
17	Can2+ Ecu
18	Can2- Ecu
19	Dout1
20	Dout2
21	rs232 TX Ecu
22	rs232 RX Ecu



Deutsch 37pin.

Deutsch 22pin.

Motorsport Connectors



- Display	LCD display + graphical portion
- Backlight	White or red
- Ambient Light sensor	Yes
- Alarm LEDs	6 RGB freely configurable
- Shift Lights	10 RGB LEDs freely configurable
- CAN connections	3
- ECU connections	CAN, RS232 or OBDII
- ECU compatibility	+500 industry leading ECUs
- External modules connection	Yes
- Expansion CAN connection	GPS, Channel expansion, Lambda Controller, SmartyCam
- Connectors	2 Motorsport connectors
- Analog inputs	8 fully configurable, max 1.000 Hz each
- Digital inputs	4 speed inputs , lap signal, coil RPM input
- Digital outputs	2
- Accelerometer	Internal Three-axial $\pm 5G$ +Gyroscope
- Internal memory	4Gb
- Body	Anodize Aluminum
- Pushbuttons	Metallic
- Dimensions	187,8x103x21mm
- Weight	530g
- Power consumption	400mA
- Waterproof	IP65



Our web site aim-sportline.com is constantly updated.

Please, check it frequently and download the latest versions of the firmware of your products.

